

Date of Correspondence	Planned Date of Change Implementation
	<i>June 30, 2019</i>
Change Notification Number	Sub-Supplier Change Notification Number
401	<i>If applicable</i>

Product(s) Affected

Part Number(s)				
Y070, Y080, Y670, Y680				
Change Description				
Part models are being updated to add web and gating feature. VP Logo is currently on the parts but not on the print, the database was updated to ensure they match what is being produced. No effect to fit form or function. See images for more details.				
Reason for Change				
Part models are being updated for manufacturability. The addition of the web will eliminate a small shutoff in the mold and eliminate the risk of damage and subsequent flash in this area.				
Change Level				
<table border="0" style="width: 100%;"> <tr> <td style="text-align: center;">Level 1 <input checked="" type="checkbox"/></td> <td style="text-align: center;">Level 2 <input type="checkbox"/></td> <td style="text-align: center;">Level 3 <input type="checkbox"/></td> <td style="text-align: center;">Emergency <input type="checkbox"/></td> </tr> </table>	Level 1 <input checked="" type="checkbox"/>	Level 2 <input type="checkbox"/>	Level 3 <input type="checkbox"/>	Emergency <input type="checkbox"/>
Level 1 <input checked="" type="checkbox"/>	Level 2 <input type="checkbox"/>	Level 3 <input type="checkbox"/>	Emergency <input type="checkbox"/>	

Supplemental Information

Implementation Procedure
Change will be done as a running change neither customer or supplier inventory needs to be scrapped. Reduce inventory of current revision while producing the new components. Deplete current revision components.
Testing / Validation Information
Samples will be available as required for any customer validation

Single Point of Contact

Name	Email Address
Customer Service	change@nordsonmedical.com