

## Fewer Moving Parts for **ENHANCED RELIABILITY**



**Browse our online store, with more than 9,600 stock components and technologies, most ready to ship within 24 hours.**

**30AC Series brings the first small all-plastic coupling series to the market. Offering a 1/8" flow size, this series is more reliable due to its advanced design with no external springs causing less moving parts. Its cost-efficient all-plastic thumb-latch design makes an audible click to ensure a secure connection.**

**[BUY ONLINE AT NORDSONMEDICAL.COM/SHOP](http://NORDSONMEDICAL.COM/SHOP)**

Produced in a durable natural Acetal (POM) thermoplastic, the 30AC Series is resistant to most mild chemicals. Its unique connection does not connect or interchange with any other coupling in the market making it an exclusive coupling technology. It is manufactured to be trouble free for many years of service and has been cycle tested to 100,000 connections.

### **FEATURES & BENEFITS**

- Advanced plastic-latch couplings
- Cost-effective, all-plastic thumb-latch design
- Resistant to most mild chemicals
- Audible click when coupled
- No external springs and fewer moving parts for enhanced reliability
- Cycle tested to 100,000 connections
- Does not connect or interchange with other thumb-latch couplings

### **MATERIALS & CONSTRUCTION**

- **Bodies, Terminations and Latch:** Acetal (POM)
- **Internal Valves:** Acetal (POM)
- **Internal Valve Springs:** 316 Stainless Steel
- **O-rings:** Buna-N (others available)